



PRODUCT SPECIFICATION SHEET

WATER SOAKING OIL TANK SPONGE

BRAND:



TOP SPEC:

Available In
0.5L & 1L

PAGE

1/1

Product Description

The Oil Tank Sponge is weighted so that it lays flat on the bottom of your tank. Containing super absorbent polymers which soaks up any water but is impervious to fuel.

When the tank sponge is full it can be removed and replaced.

Removing the water in your tank will help maintain the quality of your fuel and enable your system to run cleaner and more efficiently, giving you the peace of mind that your fuel will work to its maximum capability.

Water build up or condensation naturally happens in all fuel storage tanks (especially metal ones) because of the constant atmospheric temperature changes. Water contamination then settles at the bottom of the tank.



Main Features

- Easily removes water from the bottom of an oil tank
- Lies flat at the bottom of your tank
- Maintains the quality of your fuel and enable your system to run cleaner
- Available in 0.5L or 1L capacities

Tips & Advice

If there is water present in fuel (Kerosene or Gas Oil) a number of problems can occur:

- 1) Water can enter the heating system instead of the fuel and cause damage to the burner or boiler.
- 2) Water can increase the growth of bacteria and as a result promote tank sludge.
- 3) The presence of water will rapidly increase rusting of a metal tank and metal components in the heating system.
- 4) Water can freeze in the tank which can then cause the fuel to degrade.

Condensation occurs in most Heating Oil and Red Diesel tanks which can not only contaminate the fuel, but causes rust to develop, unseen, in the bottom of steel tanks.

The tank sponge can be purchased individually or as part of a water removal kit, which includes other products to help you combat the problem for good. Save 10% on the tank sponge when purchased with a kit, or take a look at our full range of Oil Tank Water Removal products for more options to browse from.

Unwind the retrieval cord and drop the soaker into the tank while holding on to it, leave the cord in a position where it is safe from dropping into the tank, use this cord to pull the soaker out of the tank 48 hours later. Disposed of the used soaker in the correct manner, usually into the oily waste products skip at a local recycling centre.

Additional Information

Part Number

0.5L Capacity Sponge

WAS-10

1L Capacity Sponge

WAS-15

NEED MORE INFORMATION?

○ 01373 822220

○ sales@atkinsonequipment.com

○ www.atkinsonequipment.com